

FLOOR CARE PROGRAMME

LONSEAL SMOOTH SURFACE SHEET VINYL FLOORING

PREPARING THE FLOOR

- Floor should be clean and free of old finishes and dirt.
- Sweep floor if necessary, removing any gross soiling.
- Dilute **Stipeze Speed Stripper**, 1:6 with hot water
- Apply solution liberally to floor, using a mop and bucket.
- Allow stripper to stay on floor for 5-10 minutes.
- Scrub floor with floor machine using a green/black pad.
- Pick up slurry with a wet vacuum or mop and bucket.
- Apply clean rinse water to floor, with a clean rinse mop.
- Allow to dry. – Vacuum or air dry
- Check floor for stripper residue with palm of hand, prior to moving to next step.

REMEMBER:

- Do not allow stripper solution to dry on floor.
- Pay particular attention to edges and corners.

APPLICATION

- Apply 2 thin coats of Technique Sealer, using a clean Rayon Hammerhead Mop.
- Outline the area to be finished, then fill in the outlined area with an overlapping figure-eight mopping pattern.
- Follow up the Sealer coats, by applying 3 thin coats of **Vectra Floor Finish** (gloss) or **Impesscare** (Satin Finish) in a similar manner.

REMEMBER

- Keep the mop wet, but not dripping.
- Stay 10-20cm away from the edges and baseboards.
- Allow 30-40 minutes drying time between coats to ensure that each coat has dried completely, before progressing to next coat.

DO NOT leave **Technique Sealer** as the topcoat as it is not slip resistant to **AS/NZS 3661.11993** – Slip Resistance of Pedestrian Surfaces.

DO NOT return unused sealer or finish to its original container. Dispose of through an Approved sewer system

MAINTENANCE

- Keep surface free of dust and dirt by sweeping daily.
- Damp mop heavily soiled areas using a solution of **View Quick Cleaner**, dilute at 1:40 and use a Cotton/Rayon Blend Hammerhead Mop.
- **DO NOT** use hot water, as it will damage the surface of the floor finish.
- If a high gloss is desired, floor can be buffed using a clean Red Nylon floor pad under a single disk polisher - low speed.
- Floor can also be spray-buffed using a clean Red Nylon Pad and **Snapback Spraybuff** diluted to 1:4
- As the floor finish wears, scrub thoroughly using a Green Nylon Pad and **View Quick Cleaner** at a dilution of 1:30.
- Rinse off with clean cold water.
- Allow to dry, then apply 1-2 coats of **Vectra Floor Finish** or **Impesscare**.

HELPFUL HINTS

- Clean mops and other equipment with clean water after each use.
- Do not use Rayon finish mop for any purpose other than to apply finish.
- Typical machine cleaning at monthly intervals, or as needed, with routine wet mopping daily, or as needed.
- Use of suitable walk-off matting is strongly advised as it reduces tracked in grit and moisture.

For further information regarding the maintenance of the Lonseal range of flooring products please contact **JohnsonDiversey NZ Ltd on freephone 0800 803 615**